


How to update the software in USB Memory Phone

1. Plug USB Memory Phone into your PC USB port.
2. Double click “**My Computer**” at the desktop, a removable disk and a CD-ROM named “**Autorun**” will be seen. Format the removable disk.
3. Install the program which you want to auto-run when the USB Memory Phone is connected to PC.
4. Copy the whole folder of the program to the removable disk. For example, If MSN was installed, please copy the folder **MSN Messenger** to the removable disk.
5. In the “**AutoRun**” disk, you will see three files: **AutoRun.exe**, **AutoRun.inf** and **Config.ini**., Copy the **Config.ini** file to the removable disk.

It is a configuration file. In order to update the auto-run program, it must be re-edited.



Four parameters will be seen in the file. They are **CopyRequest**, **CopyFolder**, **OpenCount** and **Open0**.

Leave **CopyRequest** and **CopyFolder** unchanged.

OpenCount=1 means that 1 program will be auto-run when the USB Memory Phone is connected to PC. If 2 programs will auto-run, please change “**OpenCount=1**” to “**OpenCount=2**”.

CopyFolder indicates the path of the program which will auto-run.

For example: If the folder **MSN Messenger** was copied into the removable disk, the path should be: **CopyFolder=MSN Messenger\msnmgr.exe**

Note: Copy programs files must be put into root directory.